

[LANCIA](#) / [YPSILON](#) / [1.3 JTD](#) / [PROCEDURES](#) / [33 BRAKING SYSTEM](#) / [3320 DRUM BRAKES](#) / [3320B REAR DRUM BRAKES](#)
/ 3320B30 LH OR RH REAR BRAKE DRUM (ONE) R R

2429162 - 3320B30 lh or rh rear brake drum (one) r r

 Removing ([Refitting](#) )

Position the vehicle on the ramp.


FOR LEFT REAR BRAKE DRUM

Proceed with removal - [4450B06 left rear wheel r r](#) .

FOR RIGHT REAR BRAKE DRUM

Proceed with removal - [4450B08 right rear wheel r r](#) .

1. Undo the pins (1a) and remove the rear brake drum (1b).



 Refitting ([Removing](#) )

Place the rear brake drum back in its housing and fix it tightening the pins to the recommended torque.

	Fastening	Component	Ø	Value (daNm)
-	Pin	REAR BRAKE DRUM	M8	(Wheel hub side) 1.0 ÷ 1.4

FOR LEFT REAR BRAKE DRUM

Proceed with refitting - [4450B06 left rear wheel r r](#) .

FOR RIGHT REAR BRAKE DRUM

Proceed with refitting - [4450B08 right rear wheel r r](#) .

Remove the car from the ramps.