

[LANCIA](#) / [YPSILON](#) / [1.3 JTD](#) / [PROCEDURES](#) / [55 ELECTRICAL EQUIPMENT](#) / [5570 ACCESSORIES](#)
/ [5570T CAR RADIO AND CAR TELEPHONE](#) / 5570T90 FRONT SPEAKER - R R

2429443 - 5570T90 front speaker - r r

 Removing ([Refitting](#) )


- [7005C44 interior handle panel - r r](#)
- [7005M11 Driver's front door electric window control SWITCH - R.R.](#)
- [7005M12 passenger side front door electrically operated window switch - r r](#)
- [7005E12 corner cover of one front side door, lh or rh r r](#)
- [7005E08 front side door interior panel r r](#)

1. Disconnect the loudspeaker's electrical connection.

	Name	Connector
1	Speaker in driver's .front door	P35

	Name	Connector
1	Speaker in front passenger door	P36

2. Undo the bolts.
3. Remove the speaker.



 Refitting ([Removing](#) )

Check that the speaker is not damaged.

Position the speaker and secure it using the bolts.

Connect the electrical connection.

- [7005E08 front side door interior panel r r](#)
- [7005E12 corner cover of one front side door, lh or rh r r](#)
- [7005M12 passenger side front door electrically operated window switch - r r](#)
- [7005M11 Driver's front door electric window control SWITCH - R.R.](#)
- [7005C44 interior handle panel - r r](#)

Check the operation of the speaker.