

2429493 - 7005C44 interior handle panel - r r


 Removing ([Refitting](#) )

- 1. Undo the trim fixing bolt.
- 2. Move the trim (2a) releasing the retainers (2b).
- 3. Disconnect the electrical connection.

	Name	Connector
3	Driver's front tweeter speaker	P45

	Name	Connector
3	Front passenger side tweeter speaker	P46

- 4. Keep the trim



 Refitting ([Removing](#) )

- Check that the trim and the tweeter are not damaged.
- Connect the electrical connection.
- Position the trim fitting the retainers.
- Tighten the retaining bolt.
- Check that the interior handle and the speaker are working.